



1. Review package contents



- Impulse 400D
- Line cord (based on country)

If anything is missing or damaged please contact your supplier

2. Installation



1. Secure the Impulse 400D into the rack space
2. Make all appropriate I/O connections on the back of the unit
3. Connect an Ethernet Cable from a management network to the MGMT port
4. Connect the line cord and move the power switch from 0 to I to power on the unit

3. Management

The Impulse 400D is configured and controlled through either the built in web interface or through the API. To change the network settings, use the steps below:

- Management IP: DHCP
Subnet: 255.255.255.0
Gateway: 0.0.0.0



Username: admin
Password: mpeg101

1. From the home screen press any button to navigate to the main menu
2. Use the arrow keys to navigate to "System", then press OK
3. Use the arrow keys to navigate to "Unit Networking", then press OK
4. Use the arrow keys to navigate to "MGMT Configuration", then press OK
5. Press OK again
6. Use the arrow keys to navigate to "IP Mode", then press OK
7. Use the arrow keys to select either "Static" or "DHCP", then press OK
8. If set to "DHCP" the unit will now get an IP address from the DHCP server. If set to "Static", use the arrow keys to set the address, pressing OK after each line is configured.
9. Open a web browser and type: <http://<IP Address>>